

SGI® Altix® XE1300 Cluster Quick Reference Guide

007-4979-001

CONTRIBUTORS

Written by Mark Schwenden and Jim Ostrom

Illustrated by Jim Ostrom

Production by Jim Ostrom. Additional contributions by Matthias Blankenhaus, Edward Mascarenhas, and James Rada

COPYRIGHT

© 2002-2007 SGI. All rights reserved; provided portions may be copyright in third parties, as indicated elsewhere herein. No permission is granted to copy, distribute, or create derivative works from the contents of this electronic documentation in any manner, in whole or in part, without the prior written permission of SGI.

LIMITED RIGHTS LEGEND

The electronic (software) version of this document was developed at private expense; if acquired under an agreement with the USA government or any contractor thereto, it is acquired as “commercial computer software” subject to the provisions of its applicable license agreement, as specified in (a) 48 CFR 12.212 of the FAR; or, if acquired for Department of Defense units, (b) 48 CFR 227-7202 of the DoD FAR Supplement; or sections succeeding thereto. Contractor/manufacturer is Silicon Graphics, Inc., 1140 East Arques Avenue, Sunnyvale, CA 94085-4602.

TRADEMARKS AND ATTRIBUTIONS

Silicon Graphics, SGI, and the SGI logo are registered trademarks of SGI., in the United States and/or other countries worldwide.

Voltaire is a registered trademark of Voltaire Inc.

Scali Manage is a trademark of Scali AS, Oslo Norway.

SMC is a registered trademark of SMC Networks Inc.

Linux is a registered trademark of Linus Torvalds.

Unix is a registered trademark of the Open Group.

Windows is a registered trademark of Microsoft Corporation.

InfiniBand is a trademark of InfiniBand Trade Association.

PBS Professional is a trademark of Altair Grid Technologies, LLC.

All other trademarks mentioned herein are the property of their respective owners.

Record of Revision

Version	Description
001	March 2007 First publication.

Contents

1. SGI Altix XE1300 Cluster Quick-reference	9
Overview	9
Site Plan Verification	10
Unpacking and Installing a Cluster Rack	11
Booting the XE1300 Cluster	12
Head Node Controls and Indicators	12
Compute Node Controls and Indicators	14
Cluster Configuration Overview.	16
Power Down the Cluster	21
Powering Off Manually	22
Ethernet Network Interface Card (NIC) Guidelines	23
Cluster Management (Head Node) IP Addresses	23
Changing the NIC1 (Customer Domain) IP Address	24
Cluster Compute Node IP Addresses	26
Switch Connect and IP Address	26
Web or Telnet Access to the Gigabit Ethernet Switch.	26
Gigabit Ethernet Switch Addressing for Compute Traffic	27
Serial Access to the SMC Switch	28
InfiniBand Switch Connect and IP Address	29
Web or Telnet Access to the Switch.	29
Serial Access to the Switch	30
Using the 1U Console Option	31
Installing or Updating Software	32
Accessing BIOS Information.	32
Scali Manage Troubleshooting Tips	33

NFS Quick Reference Points 34
Related Publications 35
Third-Party Clustering Documents 37
Customer Service and Removing Parts 38
Contacting the SGI Customer Service Center 39
Cluster Administration Training from SGI 39
2. Administrative Tips and Adding a Node 41
Administrative Tips 42
Start the Scali Manage GUI 43
Head Node Information Screen 45
Adding a Node Starting from the Main GUI Screen 46
Adding a Cluster Compute Node 48
Selecting the Server Type 50
Network BMC Configuration 51
Select Preferred Operating System 52
Node Network Configuration Screen 53
DNS and NTP Configuration Screen 54
NIS Configuration Screen 55
Scali Manage Options Screen 56
Configuration Setup Complete Screen 57
Checking the Log File Entries (Optional) 58
Setting a Node Failure Alarm on Scali Manage 59
3. IPMI Commands Overview 67
User Administration 68
Typical ipmitool Command Line 68
Adding a User to the BMC 68
Configuring a NIC 68
Display a current LAN Configuration 68
Configure a Static IP Address 68

Serial-over-lan Commands	69
Configuring SOL	69
Connecting to Node Console via SOL	70
Deactivating an SOL Connection	70
Sensor commands	70
Displaying all Objects in SDR	70
Displaying all Sensors in the System	70
Displaying an Individual Sensor	70
Chassis Commands	71
Chassis Identify	71
Controlling System Power	71
Changing System Boot Order	71
SEL Commands	71

SGI Altix XE1300 Cluster Quick-reference

Overview

Your SGI® Altix® XE1300 cluster system ships with a variety of hardware and software documents in both hard copy and soft copy formats. Hard copy documents are in the packing box and soft copy documents are located on your system hard disk in `/usr/local/Factory-Install/Docs`.

Additional third-party documentation may be shipped on removable media (CD/DVD) included with your shipment.

This document is intended as an overview of some of the common operations that system administrators may have to perform to set-up, boot, re-configure (upgrade) or troubleshoot the SGI Altix XE1300 cluster.

The SGI Altix XE1300 cluster is a set of SGI Altix XE310 servers (compute nodes), and one or more SGI Altix 240 servers (head nodes) networked together, that can run parallel programs using a message passing tool like the Message Passing Interface (MPI). The XE1300 cluster is a distributed memory system as opposed to a shared memory system like that used in the SGI Altix 450 or SGI Altix 4700 high-performance compute servers. Instead of passing pointers into a shared virtual address space, parallel processes in an application pass messages and each process has its own dedicated processor and address space.

Just like a multi-processor shared memory system, a cluster can be shared among multiple applications. For instance, one application may run on 16 processors in the cluster while another application runs on a different set of 8 processors. Very large clusters may run dozens of separate, independent applications at the same time.

Typically, each process of an MPI job runs exclusively on a processor. Multiple processes can share a single processor, through standard Linux context switching, but this can have a significant effect on application performance. A parallel program can only finish when all of its sub-processes have finished. If one process is delayed because it is sharing a processor and memory with another application, then the entire parallel program is delayed. This gets slightly more complicated when systems have multiple processors (and/or multiple cores) that share memory, but the basic rule is that a process is run on a dedicated processor core.

There are three primary hardware component types in the rackmounted cluster:

- Head node(s)
(SGI Altix 240 servers)
- Compute nodes
(SGI Altix 310 servers)
- Network interconnect components
(Gigabit Ethernet switches, InfiniBand switches, PCI cards, and cables)

The head node is connected to the interconnect network and also to the “outside world”, typically via the local area network (LAN). The head node is the point of submittal for all MPI application runs in the cluster. An MPI job is started from the head node and the sub-processes are distributed to the cluster compute nodes from the head node. The main process on the head node will wait for the sub-processes to finish. For large clusters or clusters that run many MPI jobs, multiple head nodes may be used to distribute the load.

The compute nodes are identical computing systems that run the primary processes of MPI applications. These compute nodes are connected to each other through the interconnect network.

The network interconnect components are typically Gigabit Ethernet or InfiniBand. The MPI messages are passed across this network between the processes. This compute node network does not connect directly to the “outside world” because mixing external and internal cluster network traffic could impact application performance.

Site Plan Verification

Ensure that all site requirements are met before you install and boot your system. If you have questions about the site requirements or you would like to order full-size floor templates for your site, contact a site planning representative by e-mail (site@sgi.com).

Unpacking and Installing a Cluster Rack

When your system is housed in a single rack, the cluster components come rackmounted and cabled together and a document describing how to unpack and install the rack should be included with the system. See the *SGI Altix XE System Rack Installation Instructions* (P/N 007-4902-00x). Follow the instructions provided in that manual to safely and properly unpack and install your rack system. Ensure all rack power distribution units are properly plugged in and the circuit breakers are switched to **(On)**. All units within the rack should be connected to power before booting.

Multi-rack cluster systems require connection of special interconnect cables between racks. The *Manufacturing System Diagram* document (P/N 007-4944-00x) shipped with your cluster system describes the inter-rack cable connections.

If you have arranged for SGI field personnel to install the system rack(s), contact your service representative. After your cluster rack(s) are installed, refer back to this guide to continue working with your SGI cluster system.

Booting the XE1300 Cluster

Power on any mass storage units attached to your cluster, then press the power button on the front of the head node (see callout C in Figure 1-1) and let it fully boot. Repeat the process on all the other nodes (compute nodes) in the cluster.

Head Node Controls and Indicators




Figure 1-1 SGI Altix XE240 Head Node Controls and Indicators

Table 1-1 SGI Altix XE240 Head Node Controls and Indicators

Callout	Feature	Description
A	NIC 2 Activity LED	Continuous green light indicates a link between the system and the network interface card to which it is connected.
B	NIC 1 Activity LED	Blinking green light indicates network interface card 1 activity
C	Power/Sleep button	Powers the system On/Off. Puts the system in an ACPI sleep state.
D	Power/Sleep LED	Constant green light indicates the system has power applied to it. Blinking green indicates the system is in S1 sleep state. No light indicates the power is off or is in ACPI S4 or S5 state.

Table 1-1 (continued) SGI Altix XE240 Head Node Controls and Indicators

Callout	Feature	Description
E	Hard disk drive activity LED	Blinking green light indicates hard disk activity (SAS or SATA). Unlighted LED indicates no hard disk drive activity.
F	System status LED	Solid green indicates normal operation. Blinking amber indicates degraded performance. Solid amber indicates a critical or non-recoverable condition. No light indicates the system POST is running or the system is off.
G	System Identification LED	Solid blue indicates system identification is active. No light indicates system identification is not active.
H	System Identification Button/LED	Press this button once to activate the System Identification LED. Press the button again to de-activate the System Identification LED. Solid blue indicates system identification is active. No light indicates system identification is not active.
I	Reset Button	Reboots and initializes the system.
J	USB 2.0 port	Allows attachment of a USB component to the front of the node.
K	NMI button	Puts the node in a halt-state for diagnostic purposes.
L	Video Port	Allows attachment of a video monitor to the front of the chassis. Note the front and rear video ports cannot be used at the same time.

Compute Node Controls and Indicators




Figure 1-2 SGI Altix XE310 Compute Node Controls and Indicators

Table 1-2 SGI Altix XE310 Compute Node Controls and Indicators

Feature	Description
RESET	Press the reset button to reboot only the node board controlled by that control panel.
POWER	Press power button to apply or remove power only to the node board controlled by that control panel. Pressing this button removes the main power but keeps standby power supplied to the node board.
Overheat/Fan fail	When the Overheat/Fan Fail LED flashes, it indicates that a fan has failed. When the Overheat/Fan Fail LED is on continuously, it indicates that an overheat condition has occurred, which may be caused by cables obstructing the airflow in the system or the ambient room temperature being too warm.
NIC2	Indicates network activity on LAN2 when flashing.
NIC1	Indicates network activity on LAN1 when flashing.
HDD	Channel activity for the hard disk drive (HDD). This light indicates SATA drive activity on the node board when flashing.
Power	Indicates power is being supplied to the system's power supply unit. This LED should normally be illuminated when the system is operating.

Cluster Configuration Overview

The following four figures are intended to represent the general types of cluster configurations used with SGI XE1300 systems.

Note: These configuration drawings are for informational purposes only and are not meant to represent any specific cluster system.

Figure 1-3 on page 17 diagrams a basic Gigabit Ethernet configuration using a single Ethernet switch for node-to-node communication.

Figure 1-4 on page 18 illustrates a dual-switch cluster configuration with one switch handling MPI traffic and the other used for basic cluster administration and communication.

Figure 1-5 on page 19 is an example configuration using one Ethernet switch for general administration and one InfiniBand switch for MPI traffic.

Figure 1-6 on page 20 shows a configuration with one Ethernet switch used for administration, one Ethernet switch for NAS, and an Infiniband switch used for handling MPI traffic.




Figure 1-3 Basic Cluster Configuration Example Using a Single Ethernet Switch




Figure 1-4 Dual-Ethernet Switch Based Cluster Example




Figure 1-5 Single Ethernet and Single InfiniBand Switch Configuration Example




Figure 1-6 Dual Ethernet Plus Infiniband Switch Cluster Configuration Example

Power Down the Cluster

Note: You can also use the baseboard management controller (BMC) interface to perform power management and other administrative functions. Refer to the *Altix XE310 User's Guide*, publication number 007-4960-001, for more information about the BMC interface.

You can use the Scali parallel shells tools suite to perform remote power management from the head node. Login to the head node as root, and use the `/opt/scali/sbin/power` command to manage the system.

```
# power -H
```

Usage:

```
/opt/scali/sbin/power [option] [nodelist <on|off|cycle|status>]
```

Example:

Use the following command to power cycle cluster nodes 001 through 032:

```
power c11n[001-032] -cycle
```

If your cluster uses the Scali Manage administrative software (release 5.3), you can power-off specific nodes or the entire system using the graphical user interface. Select `Management Menu>Power Mgt>Power Off`. The compute nodes can be halted from the Scali GUI by selecting the nodes and choosing “halt system” and “power down” from the System Management menu. A command line interface is also available to power-on/off or check status.

Note: Refer to the *Scali Manage User's Guide* for more information. You must have root privileges to perform these types of tasks.

Powering Off Manually

To power off your cluster system manually, follow these steps:



Caution: If you power off the cluster before you halt the operating system, you can lose data.

1. Shut down the operating system by entering the following command:

```
# init 0
```
2. Press the power button on the head node(s) that you want to power off. You may have to hold the button down for up to 5 seconds. You may power off the nodes in any order.
3. To power off the compute nodes, press the power button (for up to 5 seconds) on the front panel of each unit (see Figure 1-1 on page 12).
4. To power off optional storage units in the cluster rack, press the power button(s) on their rear panel to the OFF (O) position.

Ethernet Network Interface Card (NIC) Guidelines

While Ethernet ports are potentially variable in a cluster, the following rules generally apply to the cluster head node:

- The server motherboard's nic1 is always a public IP in the head node.
- The server motherboard's nic2 is always a private administrative network connection.
- Nic3 is always a PCI expansion controller port. It is typically used to handle MPI traffic.

Cluster Management (Head Node) IP Addresses

The primary head node of the cluster (head node1) is also known as the cluster management head node. Head node 1 is where the cluster management software is installed and it has the following technical attributes:

- On-board network interface (nic1) IP address is variable (used as public Ethernet access).

Important: The on-board network interface 1 (nic1) IP address is the factory IP address setting. This setting needs to be changed to reflect the customer domain IP address before connection to the LAN. See the section “Changing the NIC1 (Customer Domain) IP Address” on page 24.

- On-board network interface 2 (nic2) (10.0.10.1) is always used as the management and administration (internal) network port on the primary head node of the cluster.

Note: In the case of a Gigabit Ethernet solution, nic3 is used for MPI traffic. In this case nic3 is on a PCI expansion card.

- The optional Infiniband HCA IP address is 192.168.10.1.
- Board Management Control (BMC) static IP address. The Intelligent Platform Management Interface (IPMI) uses IP address 10.0.30.1 to make controller connections to the other BMCs that exists in the cluster.

It is possible to have additional head nodes on the cluster. Table 1-3 lists examples of the head node port IP address information for more than one head node. Baseboard Management Control routes through nic1 in any additional head nodes added to the cluster. Each fourth octet number in an address iterates by one number as a head node is added.

Table 1-3 Head Node Ethernet Address Listings

Head node number	Internal management IP address nic2	(GigEnet) MPI NAS/SAN option nic3	Infiniband IP address	Baseboard Management Control or IPMI address nic1
1	10.0.10.1	172.16.10.1	192.168.10.1	10.0.30.1
2	10.0.10.2	172.16.10.2	192.168.10.2	10.0.30.2
3	10.0.10.3	172.16.10.3	192.168.10.3	10.0.30.3
4	10.0.10.4	172.16.10.4	192.168.10.4	10.0.30.4

Changing the NIC1 (Customer Domain) IP Address

The “external” IP address assigned to NIC1 must be changed to reflect the new network environment. In addition a set of network parameters specific to your networking environment need to be specified. This can be accomplished by passing a network configuration file to a script. The script is named **config_headnode** and is located at: `/usr/local/Factory-Install/Scripts`.

The network configuration file contains all relevant parameters used by the nic1 port to communicate with your local area network.

The file is located at: `/usr/local/Factory-Install/Scripts/network.cfg`

You should edit this file with your favorite Unix or Linux text editor. **Do not** use a Windows based text editor as it may leave carriage return characters at the end of each line causing the script to fail.

The configuration file format is line-oriented, e.g. you cannot break any of the lines into two or more lines. In addition, it adheres to the following formatting rules:

- White spaces are supported.

- Empty lines are supported.
- Comments are line-oriented and begin with the # sign.
- Everything after the hash sign is ignored.
- The variable identifier (all identifiers left to the assignment operators) need to be all uppercase, e.g. NEW_HEAD_NODE_NAME.
- The assignment operator is mandatory.
- Every variable needs to have a value.
- List declarations, (as in DNS_SERVER_LIST in the example configuration file that follows), need to be comma separated.

Only minimal error checking is done to ensure the configuration file has the right format. The user is responsible for the updated local content. You must have root privilege to execute the script.

After you have edited the file with your local addresses and domain information, launch the following script at your head node console to change Scali's network settings:

```
# cd /usr/local/Factory-Install/Scripts/
Then execute the script like this:
# ./config_headnode -f network.cfg
```

After the script has made the necessary changes, it will automatically reconfigure all the compute nodes. Then it will reboot the head node. An example of the configuration file looks like this:

```
# This is a comment.
NEW_HEAD_NODE_NAME=dab
ETH_DEV=eth0
# another comment
NEW_SUBNET_NAME=163.154.16.0/24
NEW_SUBNET_ADDR=163.154.16.0
NEW_SUBNET_MASK=255.255.255.0
NEW_IP_ADDR=163.154.16.197
NEW_GW_ADDR=163.154.16.1
NIS_DOMAIN=enr.sgi.com
NIS_SERVER_LIST=broadcast
DNS_DOMAIN_LIST=enr.sgi.com
DNS_SERVER_LIST=192.26.80.2, 163.154.16.4, 163.154.16.5
NTP_SERVER_LIST=127.127.1.0
```

Cluster Compute Node IP Addresses

The cluster system can have multiple compute nodes that each use up to three IP address points (plus the Infiniband IP address). As with the head nodes, each fourth octet number in an address iterates by one number as a compute node is added to the list. Table 1-4 shows the factory assigned IP address settings for compute nodes one through four.

Table 1-4 Compute node Ethernet address listings

Compute node number	Management IP address nic1	Infiniband IP address	Gigabit Ethernet solution nic2	Baseboard Management (BMC) or IPMI address nic1
Compute node1	10.0.0.1	192.168.1.1	172.16.1.1	10.0.40.1
Compute node2	10.0.0.2	192.168.1.2	172.16.1.2	10.0.40.2
Compute node3	10.0.0.3	192.168.1.3	172.16.1.3	10.0.40.3
Compute node4	10.0.0.4	192.168.1.4	172.16.1.4	10.0.40.4

Note: The management (internal cluster administration port) IP address and the BMC/IPMI address are shared by the same network interface port (nic1). The circuitry allows the same physical Ethernet port to share two separate IP address references.

Switch Connect and IP Address

Table 1-5 lists the factory IP address for switches that may be used with your cluster.

Web or Telnet Access to the Gigabit Ethernet Switch

Your switch(s) setup is configured in the factory before shipment and should be accessible via telnet or a web browser. You can connect to a console directly from the head node through the administration network using telnet.

To access the first switch via telnet:

```
telnet 10.0.20.1
```

Login as the administrator:

```
login admin
passwd: admin
```

Web access would be:

```
http://10.0.20.1
```

Note: The fourth IP octet grows sequentially for each additional switch. For example, access to switch 2 would be at IP address 10.0.20.2 via telnet or the web.

Table 1-5 Switch IP Addresses

SMC switch number	IP address
SMC switch1 (stacked or single)	10.0.20.1
SMC switch2 (stacked or single)	10.0.20.2
SMC switch3 (stacked or single)	10.0.20.3

Gigabit Ethernet Switch Addressing for Compute Traffic

The SMC Gigabit Ethernet switch is configured with the IP addresses shown in Table 1-6 when used with a NAS/SAN option or message passing interface (MPI) traffic. The fourth IP octet grows sequentially for each additional switch used.

Table 1-6 SMC Gigabit Ethernet Compute Traffic SMC Switch IP Addresses

SMC GigEnet NAS/SAN switch number	IP address
SMC Switch1 (stacked or single)	172.16.20.1
SMC Switch2 (stacked or single)	172.16.20.2
SMC Switch3 (stacked or single)	172.16.20.3

Serial Access to the SMC Switch

Use of a serial interface to the switch should only be needed if the factory assigned IP address for the switch has been somehow deleted, altered or corrupted. Otherwise, use of the web or telnet access procedure is recommended. To use a serial interface with the switch, connect a laptop, or PC to the switch's console port. See Figure 1-7 for the location of the console port.




Figure 1-7 SMC Switch Connectors Example

1. Establish a command line interface (CLI) and list the port connection settings:

```
Port Settings
  Bits Per Second=19200
  Data bits=8
  Parity=None
  Stop Bits=1
  Flow Control=none
```

2. In order to verify and save any new settings type the following:

```
console# show running-config (make sure your settings are intact)
console# copy running-config startup-config (it will ask for a file name)
console# file name? startup
```

Note: Any changes made to the switch port settings through the serial interface or Web interface are **not** saved unless the previous steps have been executed.

3. Power cycle the switch by disconnecting and reconnecting its power cable.

InfiniBand Switch Connect and IP Address

Table 1-7 on page 30 lists the factory IP address settings for your InfiniBand switch(s) used with the cluster. For clusters with greater than 288 network ports, consult SGI Professional Services for specific IP address configuration information.

Web or Telnet Access to the Switch

Your InfiniBand switch(s) setup is configured in the factory before shipment and should be accessible via telnet or a web browser.

Note: There might be only one managed InfiniBand switch when multiple InfiniBand switches are used blocking configurations.

To access the first InfiniBand switch via telnet:

```
telnet 10.0.21.1
```

Login as the administrator:

```
login admin
```

```
passwd: 123456
```

Web access would be:

```
http://10.0.21.1
```

javaws (java Webstart) is required for use of the InfiniBand fabric GUI.

SLES 9 service pack 3 location of javaws is:

```
/usr/java/j2re1.4.2_12/javaws/javaws
```

SLES 10 location of javaws is: /usr/bin/javaws

Note: The fourth IP octet grows sequentially for each additional switch. For example, access to InfiniBand switch 2 would be at IP address 10.0.21.2 via telnet or the web, see Table 1-7.

Table 1-7 InfiniBand Switch IP Address Listings Example

InfiniBand switch number	IP address
InfiniBand switch1	10.0.21.1
InfiniBand switch2	10.0.21.2
InfiniBand switch3	10.0.21.3

Serial Access to the Switch

You should connect a Voltaire serial cable (either DV-9 to DB-9 or DB-9 to DB-9) that comes with the 24-port switch, from a PC/laptop directly to the switch for serial access. Use of a serial interface to the switch should only be needed if the factory assigned IP address for the switch has been somehow deleted, altered or corrupted. Otherwise, use of the web or telnet access procedure is recommended.

Note: For Voltaire switches 96-ports or larger always use a DB-9 serial cable.

To interface with the switch, use the connected laptop or other PC to:

1. List the port connection settings. Default settings are:

```
Port Settings
Bits Per Second=38400
Data bits=8
Parity=None
Stop Bits=1
Flow Control=xon/xoff
```

Note: For clusters with InfiniBand switches, the fourth Octet IP address will increment for each InfiniBand switch added. See Table 1-7 for an example list.

2. Click “ok” if the settings are acceptable. In the serial interface window on the PC, press enter several times until you see the “ISR-xxxx login:” prompt, then enter the following:
ISR-xxxx login: **admin**

```
ISR-xxxx login: Password: 123456
ISR-xxxx> enable
ISR-xxxx> Password: voltaire
```

3. Set up the network for your InfiniBand switch cluster configuration using the following information and Table 1-7 on page 30.

Enter the following commands to set up the network:

```
ISR-xxxx# config
ISR-xxxx(config)# interface fast
ISR-xxxx(config-if-fast)# ip-address-fast set [10.0.20.x]
255.255.0.0
ISR-xxxx(config-if-fast)# broadcast-fast set 10.0.255.255
ISR-xxxx(config-if-fast)# exit
ISR-xxxx(config)# exit
ISR-xxxx# reset software (This reboots the 24-port InfiniBand switch)
For a 96-port or larger switch:
```

4. `ISR-xxxx# reload software`
`ISR-xxxx# fast-interface show` (This command lists the IP address)
5. Power cycle the switch by disconnecting its power cable from the plug and then plugging it back in.

Using the 1U Console Option

The SGI optional 1U console is a rackmountable unit that includes a built-in keyboard/touchpad, and uses a 17-inch (43 cm) LCD flat panel display of up to 1024 x 768 pixels. The 1U console attaches to the headnode using PS/2 and HD15M connectors or to a KVM switch (not provided by SGI). The 1U console is basically a “dumb” VGA terminal, it cannot be used as a workstation or loaded with any system administration program.

Note: While the 1U console is normally plugged into the head node on the cluster, it can be connected to any node in the system for terminal access purposes.

The 27-pound (12.27kg) console automatically goes into sleep mode when the monitor cover is closed down.

Installing or Updating Software

Scali Manage offers a mechanism to upload and install software across the cluster. This upload and installation process requires that the software installation be in RPM format. Tarball software distributions can be installed across a cluster. Please see the Scali `scarcp` (cluster remote copy) and the `scash` (cluster remote shell) commands in the *Scali Manage User's Guide*.

Instructions for installing software options or uploading additional software for your cluster using the Scali GUI are covered in Chapter 3 of the *Scali Manage User's Guide*.

Your integrated cluster also comes with a NFS mounted filesystem. The head node exports a `/data1` directory. Each compute node mounts this exported filesystem on `/cluster`. This can be used as a mechanism to install software across the cluster as well.

Customers with support contracts needing BIOS or Firmware updates, should check the SGI Supportfolio Web Page at:

<https://support.sgi.com/login>

Accessing BIOS Information

BIOS Setup Utility options are used to change server configuration defaults. You can run BIOS Setup with or without an operating system being present. You can enter and start the BIOS Setup Utility after you apply power to a head node or compute node (with a console attached) and the Power-On Self Test (POST) completes the memory test. During the POST, the following prompt displays:

SGI Altix XE240 Head Node:

Press <F2> to enter SETUP

SGI Altix XE310 Compute Node:

Pres to enter SETUP

Note: The DEL key and F2 key work only if the proper ACSII terminal settings are in place. Many Linux distributions default to varied ASCII settings. In the case of the SGI Altix 310 compute node, the DEL key must to generate an "ACSII DEL". If it does not, type Ctrl-Backspace to enter BIOS setup menu.

Note:

Important: The BIOS comes preconfigured with the SGI recommended settings. Changes to any of the BIOS settings can impact the performance of your cluster.

If CMOS/NVRAM becomes corrupted on an SGI Altix XE240 server, you may see other prompts but not the <F2>prompt:

Warning: CMOS checksum invalid

Warning: CMOS time and date not set

Under these circumstances, you should contact your SGI service representative. Refer to the *SGI Altix XE240 User's Guide* (P/N 007-4873-00x) and *SGI Altix XE310 User's Guide* (P/N 007-4960-00x) for specific information about BIOS settings.

Scali Manage Troubleshooting Tips

This section describes some general guidelines as well as emergency procedures.

Whenever a Scali cluster parameter is changed, it is necessary to apply the configuration. This can be done either through the GUI (Provisioning > Apply All Configuration Changes) or via CLI: `scalimanage-cli reconfigure all`. Changes can be made in batches and then applied all at once.

There are situations when the GUI does not reflect the cluster configuration properly. Restarting the GUI may solve this problem.

In rare cases the Scali product enters an inconsistent state. In this state it shows abnormal behavior and refuses to take any input. In this case try to reinitialize the head node via `/etc/init.d/scance restart`.

This command must be run on the head node. If this does not change Scali's state, then you should reboot the head node. This should ensure that Scali will be in a consistent state. If you have trouble that is more hardware related, see "Customer Service and Removing Parts" on page 38.

NFS Quick Reference Points

The cluster head node exports an NFS, compute nodes import NFS on the head node. The cluster comes with a preconfigured NFS mount. The headnode exports the `/data` filesystem. The compute nodes mount head node `/data1` on `/cluster`.

You need to execute the following commands to export a filesystem via NFS from the head node:

```
# scalimanage-cli addnfsexport <head_node> <filesystem>
# /etc/init.d/scance restart
```

To import this filesystem on a particular compute node:

```
# scalimanage-cli addremotefs compute_node nfs
head_node:/filesystem mount_point
# scalimanage-cli reconfigure compute_node
```

If the compute nodes need to mount filesystems located outside the cluster, then NAT must be enabled on the head node. You need to execute the following commands on the head node:

```
# scalimanage-cli addnatSERVICE head_node ethernet_dev
# /etc/init.d/scance restart
```

Now you can access nodes outside the cluster from your compute nodes.

To mount a remote filesystem residing outside the cluster on a particular compute node you need to do the following:

```
# scalimanage-cli addremotefs compute_node nfs
external_node:/filesystem mount_point
# scalimanage-cli reconfigure compute_node
```

Related Publications

The following SGI system documents may be useful or necessary while configuring and operating your Altix XE1300 cluster system:

- *Manufacturing Audit Checklist* (P/N 007-4942-00x)
This document contains the network configuration/validation switch IP addresses for your system.
- *Manufacturing Configuration Summary* (P/N 007-4943-00x)
- *Manufacturing System Diagram* (P/N 007-4944-00x)
- *SGI Altix XE System Rack Installation Instructions* (P/N 007-4902-00x)
This manual provides instructions for unpacking, uncrating and installing a rack at your location.
- *SGI Altix XE310 User's Guide* (P/N 007-4960-00x)
This guide covers general operation, configuration, and servicing of the SGI Altix XE310 compute modules within the SGI Altix XE1300 cluster.
- *SGI Altix XE240 User's Guide* (P/N 007-4873-00x)
This guide covers general operation, configuration, and servicing of the Altix XE240 head node(s) within the Altix XE1300 cluster.
- *SGI Altix XE310 AOC-SIMSO User's Guide* (P/N 860-0472-00x)
This guide shows you how to administrate SGI Altix XE310 servers from the baseboard management controller (BMC) interface.
- *Porting IRIX® Applications to SGI® Altix® Platforms: SGI ProPack™ for Linux®*, Publication Number 007-4674-00x
This manual may be useful for any administrator porting existing IRIX applications to Linux.
- `/usr/local/Factory-Install/` on the head node
This online directory on the head node contains useful information specific to your system configuration.

- *SGI Altix® Systems Dual-Port Gigabit Ethernet Board User's Guide*, Publication Number 007-4326-00x

This guide describes the two versions of the optional SGI dual-port Gigabit Ethernet board, shows you how to connect the boards to an Ethernet network, and explains how to operate the boards. You can use the dual-port Gigabit Ethernet board to replace or supplement the built-in Ethernet network adapters in your system.

- *SGI 10-Gigabit Ethernet Network Adapter User's Guide*, Publication Number 007-4669-00x

This guide describes the SGI 10-Gigabit (Gbit) Ethernet network adapter. It shows you how to connect the adapter to an Ethernet network and explains how to operate the adapter. The manual also provides information on how to performance tune this high-speed interface card.

- *SGI ProPack 5 for Linux Start Here*, Publication Number 007-4837-00x (2006)

This document provides information about the SGI ProPack 5 for Linux release, including the major features of the release, flowcharts of disk partitions and file configurations.

- *Guide to Administration, Programming Environments, and Tools Available on SGI Altix XE Systems*, Publication Number 007-4901-001.

For internet access to these and other SGI documents, see the SGI Technical Publications Library at: <http://docs.sgi.com>. Various formats are available. This library contains the most recent and most comprehensive set of online books, release notes, man pages, and other information

Third-Party Clustering Documents

The SGI Altix XE1300 Cluster is provided in different configurations and not all the third-party documents listed here will be applicable to every system. Note that Linux is the only operating system supported with the SGI Altix XE1300 cluster.

- *Voltaire® HCA-4x0 User Manual*, Publication Number 399Z00007 (2006) Release AAA-BAA

This document describes how to install and configure the Voltaire HCA-4x0 Linux based InfiniBand software and the hardware interface cards needed for a cluster. The HCA-4x0 User Manual covers a number of technical features that are not supported with the Altix XE1300 cluster products. These include SDP, CM and GSI.

For a complete listing of supported and non-supported host stack components, see the release notes section on: “Voltaire InfiniBand Stack for SGI Altix Systems”. The release notes for the stack is included in the Voltaire software CD.

- *Voltaire® ISR 9024S/D Installation Manual*, Publication Number 399Z00002 Release AAA-CAA

This manual covers unpacking, installation, configuration, and power-up information as well as basic troubleshooting information for the 24-port InfiniBand Switch Routers.

- *Voltaire ISR 9288/ISR 9096 Installation Manual*, Publication Number 399Z40000 Release AAA-AAB

This manual covers unpacking, installation, configuration, and power-up information as well as basic troubleshooting information for the 96-port and 288-port InfiniBand Switch Routers.

- *Voltaire® Switch User Manual*, Publication Number 399Z00038 Release AAA-AAA

This manual covers technical descriptions and use of different switches; ISR9024, ISR9600 and ISR9288. Only the ISR9024, ISR9600 and ISR9288 are supported options for the Altix XE1300 cluster product. Information on managing switch usage via the Voltaire Device Manager CLI or GUI, and basic diagnostics are also covered in this manual.

- *SMC® TigerStack™ II Gigabit Ethernet Switch Installation Guide*, (2006)

Use this guide to install or configure the SMC8824M 24-port switch and the SMC8848M 48-port switch. These are stackable 10/100/1000 base-T switches used with Altix XE1300 clusters.

- *SMC® TigerStack™ II Gigabit Ethernet Switch Management Guide, (2006)*
Use this guide to manage the operations of your SMC8824M 24-port switch or SMC8848M 48-port switch.
- *Scali Manage™ User's Guide, (2006)*
This document provides an overview of a Scali system in terms of instructions for building a Scali system. Configuration guidelines for hardware and software are covered along with instructions on use and general management of the cluster system.
- *Scali Manage™ Installation Guide, (2006)*
This document describes the Scali Manage software installer that helps the user with installation of the OS, Scali software and third-party applications that are installed as RPMs.

Customer Service and Removing Parts

If you are experiencing trouble with the cluster and determine that a replacement part will be needed, please contact your SGI service representative using the information in “Contacting the SGI Customer Service Center”. Return postage information is included with replacement parts.

Removal and replacement of the hardware components that make up the head and compute nodes within the cluster are fully documented in:

- *SGI Altix XE240 User's Guide*, Publication number 007-4873-00x
- *SGI Altix XE310 User's Guide*, Publication number 007-4960-00x

These documents can be used to help troubleshoot node-level hardware problems and are included as soft copy (PDF format) on the head node's system disk at:
`/usr/local/Factory-Install/Docs`

You can also download these documents via internet, from the SGI publications library at:
<http://docs.sgi.com>

If you need to replace a node within your cluster, go to the SGI Supportfolio web page:
<https://support.sgi.com/login>

Contacting the SGI Customer Service Center

To contact the SGI Customer Service Center, call 1-800-800-4SGI, or visit:
<http://www.sgi.com/support/customerservice.html>
From outside the United States contact your local SGI sales office.

Cluster Administration Training from SGI

SGI offers customer training classes covering all current systems, including clusters. If you have a maintenance agreement in place with SGI, contact SGI Customer Education at 1-800-361-2621 for information on the time, location and cost of the applicable training course you are interested in. Or, go to the following URL site for more education information:
<http://www.sgi.com/support/custeducation/>

Customers with support contracts can also obtain information from:
<https://support.sgi.com/login>

Administrative Tips and Adding a Node

This chapter provides general administrative information section and information on starting and using the Scali Manage GUI to add a node in a Scali managed cluster. For information on using the Scali Manage command line interface to add a node, refer to the *Scali Manage User's Guide*. Basic information on starting Scali Manage, administrative passwords and factory installed files and scripts are covered in the first section of this chapter, “Administrative Tips” on page 42.

Add a node to the cluster using the following sections and accompanying screen snaps:

- “Start the Scali Manage GUI” on page 43
- “Head Node Information Screen” on page 45
- “Adding a Node Starting from the Main GUI Screen” on page 46
- “Adding a Cluster Compute Node” on page 48
- “Selecting the Server Type” on page 50
- “Network BMC Configuration” on page 51
- “Select Preferred Operating System” on page 52
- “Node Network Configuration Screen” on page 53
- “DNS and NTP Configuration Screen” on page 54
- “NIS Configuration Screen” on page 55
- “Scali Manage Options Screen” on page 56
- “Configuration Setup Complete Screen” on page 57
- “Checking the Log File Entries (Optional)” on page 58

Set a node failure “alarm” using the information in:

- “Setting a Node Failure Alarm on Scali Manage” on page 59

Administrative Tips

Root password and administrative information includes:

- Root password = **sgisgi** (head node and compute nodes)
- Ipmitool user/password info: User = **admin** Password = **admin**

See Table 1-3 on page 24 and Table 1-4 on page 26 for listings of the IPMI IP addresses for nodes.

Note:

The `ipmitool` command syntax for SGI Altix XE240 head nodes (run via the Scali Manage head node):

```
-ipmitool -I lanplus -o intelplus -H ip address command
```

The `ipmitool` command syntax for SGI Altix XE310 compute nodes (run via the Scali Manage head node):

```
-ipmitool -I lanplus -o supermicro -H ip address command
```

SGI Altix XE systems that run SLES10, release 4, can use the following service:

```
checkconfig ipmi on  
/etc/init.d/ipmi start
```

Following is the `ipmitool` command syntax for running directly from the head node (or any node) on itself. (Note the absence of the `-I -o` and `-H` options):

```
ipmitool command
```

The Scali Manage installer directory (`/usr/local/Scali###`) is the location of the code used to install Scali Cluster management Software.

The `Factory-Install` directory is located on the head node server at `/usr/local/Factory-Install`. The `/Factory-Install` directory contains software files that support the cluster integration and many files and scripts that may be helpful, including:

Under `/usr/local/`:

`/Factory-Install/Apps`

Scali, `ibhost`, intel compiler/mpi runtime libraries, `ipmitool`, etc.

`/Factory-Install/ISO:`

CD iso's of the base OS for installing Scali Cluster Manage software

`/Factory-Install/Docs`

Cluster documentation manuals (Scali, PBS Professional, Voltaire, SMC, SGI)

`/Factory-Install/Firmware`

Voltaire HCA and Voltaire switch firmware files, etc.

`/Factory-Install/CFG`

Cluster configuration files

`/Factory-Install/Scripts`

Miscellaneous utility scripts

Start the Scali Manage GUI

Login to the Scali Manage interface as root, the factory password is `sgisgi`. Use your system name and log in as root. See Figure 2-1 for an example.




Figure 2-1 Example Starting Screen for the Scali Manage GUI

Head Node Information Screen

You can view and confirm the head node information from the main GUI screen. Click on the node icon (three red stripes) for name and subnet information on your cluster head node.




Figure 2-2 Head Node Information Screen Example

Adding a Node Starting from the Main GUI Screen

Add a node when you need to upgrade. To add a cluster node, open the Clusters tree by clicking the right mouse button. Move your cursor over the cluster tree (cluster cl1 in the example screen), and click the right mouse button. Then click the left mouse button on the “New” popup window.




Figure 2-3 Scali Manage Main Screen Selections Example

Adding a Cluster Compute Node

These steps should only be taken if the cluster needs to be upgraded or re-created. Select the option “Extend existing cluster” and provide the number of servers (1 in the example). Then select the “Cluster Name” (cl1 in the example). Click “Next” to move to the following screen.




Figure 2-4 New Cluster Node Selection Example

Selecting the Server Type

Scroll down the menu and select the server type you are adding.




Figure 2-5 Node Server Type Selection Screen Example

Network BMC Configuration

Assign the new BMC IP address, stepping and BMC host name. Click OK when the appropriate information is entered. Then enter the BMC user id (**admin**) and the password (**admin**). Click “Next” to move to the following screen.




Figure 2-6 BMC Network Configuration Screen Example

Select Preferred Operating System

Click on the option to select the new node's operating system. Enter the **sgisgi** factory password or whatever new password may have been assigned. Click "Next" to move to the following screen.




Figure 2-7 Preferred Operating System Screen Selection Example

Node Network Configuration Screen

Use this screen to assign Ethernet 0 (eth0) as your network interface port. Fill in the additional information as it applies to your local network. Click “OK” to continue.




Figure 2-8 Node Network (Ethernet 0) Screen Example

DNS and NTP Configuration Screen

This screen extracts the name server numbers for use with the system configuration files. In this example, the domain name is engr.sgi.com with NTP enabled. Click “Next” when complete.




Figure 2-9 DNS and NTP Configuration Screen Example

NIS Configuration Screen

This screen allows you to specify, enable or disable a Network Information Service (NIS) for the new node. Assign your domain name and click “Next” to go to the following screen.




Figure 2-10 NIS Configuration Screen Example

Scali Manage Options Screen

This screen provides the options shown, including installation of MPI, your software version, monitor options and more. Click “Next” to move to the following screen.




Figure 2-11 Scali Manage Options Screen Example

Configuration Setup Complete Screen

This screen allows you to install the operating system and Scali Manage immediately, or store the configuration for later use. Click “Finish” after you make your selection.




Figure 2-12 Configuration Setup Complete Screen Example

Checking the Log File Entries (Optional)

You can check the log file entries during configuration of the new node to confirm that a log file has been created and to view the entries.




Figure 2-13 Optional Log File Screen Example

Setting a Node Failure Alarm on Scali Manage

This section shows how to create an alarm using a “Node Down” alarm as an example:

1. Start the GUI. See “Start the Scali Manage GUI” on page 43 if needed.
2. Using the mouse, select the “Edit Alarms” submenu from the “Monitoring” menu item.
3. Select a node (or list of nodes) for which you want to define the alarm, refer to Figure 2-14.
4. Then select “Add Alarm” to add the alarm.
5. A popup appears offering input for the alarm name and an optional description, refer to Figure 2-15.




Figure 2-14 Node Selection for Alarm Function Example




Figure 2-15 Alarm Description Pop-up Example

- 6. At this time you must enter the criteria that trigger the alarm. Click on “Add Criteria” (see Figure 2-16 on page 62.)




Figure 2-16 Add Criteria Screen Example

7. Another popup presents itself. For this example we picked a “Filter” criteria for the node status. See Figure 2-17 on page 63.




Figure 2-17 Define Chart Data Popup Example (Filter Selected)

Next we need to choose the priority for this alarm. The example assigns a critical priority for the “Node Down” alarm. We want this alarm to be triggered at most once. Therefore we leave the “Re-Trigger” value with 0. To enable this alarm, click on “Apply Alarm”, see Figure 2-18 on page 64. An alternative would be to define a re-trigger interval in seconds by providing the amount of seconds for “Re-Trigger”. This alarm does not define any action to be taken when the alarm fires. This can be easily done by selecting a predefined

action. As an example, Scali can send an e-mail to a system administrator or E-mail alias. You must pick the appropriate action and supply the e-mail address.




Figure 2-18 Applying the Alarm Example Screen

To illustrate how an alarm makes it's appearance we have intentionally brought down the node. A few seconds thereafter the GUI indicates a node failure by changing the node icon in the cluster tree, refer to Figure 2-19 on page 65. A few seconds later the alarm gets triggered and shows up in the alarm log, see Figure 2-20 on page 66.




Figure 2-19 Node Failure Icon Example Screen




Figure 2-20 Node Down Alarm Screen Example

IPMI Commands Overview

This chapter provides a set of example IPMI commands, and is not meant to be a comprehensive guide in the use of `ipmitool`. Its purpose is to briefly describe some of the commonly used IPMI commands to help you get started with your cluster administration.

Command-line utility for issuing common IPMI requests allows remote operation usage:

```
ipmitool [-v] [-I interface] [-o oemtype] [-H bmc-ip-address] [-k key]
[-U user] [-P password] [-E] command...
-v : Verbosity, can be specified multiple times -vv
-I interface : IPMI interface to use
-o oemtype : Select OEM type to support.
```

Note: Use `-o intelplus` for the SGI Altix XE240 head node. Use `-o supermicro` for the SGI Altix XE310 compute nodes.

Use `-o list` to see a list of current supported OEM types.

```
open - OpenIPMI driver (default)
lan - LAN connection (remote connection, requires -H/-U/-P arguments)
lanplus - LANplus connection (IPMI 2.0) Requires -H/-U/-P arguments be
supplied

-H bmc-ip-address : Hostname or IP address of remote BMC (-I lan only)
-k key : KG Key (System password) (-I lanplus only)
-U user : Username on remote system (-I lan only)
-P pass : Password for user on remote system (-I lan only)
-E : Read password from IPMI_PASSWORD environment variable
```

If `-E` and `-P` are not specified on a remote connection, the utility prompts for a password.

User Administration

BMC Supports multiple users, username/password is required for remote connections. The cluster is shipped with a factory username and password set on user id 2:

Username = **admin**
Password = **admin**

Typical ipmitool Command Line

```
ipmitool -I lanplus -o <oemtype> -H <bmc_ip_address> -U admin -P admin  
<command>
```

<opts> references in this document refer to the following command line arguments:

```
-I lanplus -o intelplus|supermicro -H <bmc-ip-address> -U admin -P admin
```

Adding a User to the BMC

```
ipmitool <opts> user set name <user ID> <username>  
ipmitool <opts> user set password <user id> <password>  
ipmitool <opts> user enable <user id>
```

Configuring a NIC

Display a current LAN Configuration

```
ipmitool <opts> lan print 1
```

Configure a Static IP Address

Static IP addresses are already set in the factory on LAN channel 1 of each node. Refer to Table 1-3 on page 24 and Table 1-4 on page 26 for the BMC static IP assignments.

The following commands show how to reconfigure the BMC static IP's. The "1" in the following examples indicate "channel 1" onboard nic1 controller.

```
ipmitool <opts> lan set 1 ipsrc static  
ipmitool <opts> lan set 1 ipaddr x.x.x.x
```

```
impitool <opts> lan set 1 netmask x.x.x.x
impitool <opts> lan set 1 arp respond on
impitool <opts> lan set 1 arp generate on
```

To check your lan settings:

```
impitool <opts> lan print 1
```

Serial-over-lan Commands

Serial-Over-Lan (SOL) comes preconfigured and enabled on each node of your cluster.

Configuring SOL

SGI recommends the following parameter settings for the SGI Altix XE240 head node:

```
impitool <opts> sol set character-send-threshold 50 1
impitool <opts> sol set character-accumulate-level 004 1
impitool <opts> sol set retry-interval 20 1
impitool <opts> sol set retry-count 6 1
impitool <opts> sol set non-volatile-bit-rate 115.2
```

Note: Some systems were set to a 115.2 baud rate. To see your configuration, enter the following: `impitool <opts> sol info`

SGI recommends the following parameter settings for the SGI Altix XE310 compute node:

```
impitool <opts> sol set character-send-threshold 80 1
impitool <opts> sol set character-accumulate-level 012 1
impitool <opts> sol set retry-interval 100 1
impitool <opts> sol set retry-count 7 1
impitool <opts> sol set non-volatile-bit-rate 115.2
```

Connecting to Node Console via SOL

```
ipmitool <opts> sol activate
```

Deactivating an SOL Connection

In certain cases using the Scali Manage GUI to access a console, you may need to deactivate the SOL connection from the command line to free up the SOL session.

```
ipmitool <opts> sol deactivate
```

Sensor commands

Displaying all Objects in SDR

```
ipmitool <opts> sdr list  
Ipmitool <opts> sdr dump <filename> (Dump SDR contents to a file)
```

Displaying all Sensors in the System

```
ipmitool <opts> sensor list
```

Displaying an Individual Sensor

```
ipmitool <opts> sensor get "Temp"  
Changing sensor threshold  
ipmitool <opts> sensor thresh "Temp" ucr 100
```

Thresholds are: unr, ucr, unc, lnc, lcr, lnr.

Chassis Commands

Use the following chassis commands to administrate the cluster. Note that you can also use the BMC interface to perform chassis power commands on cluster nodes.

Chassis Identify

Note: The following `ipmitool chassis indentify` command works only on the SGI Altix XE240 head nodes.

```
ipmitool <opts> chassis identify (defaults to 15 seconds)
ipmitool <opts> chassis identify off
```

Controlling System Power

```
ipmitool <opts> chassis power status
ipmitool <opts> chassis power off
ipmitool <opts> chassis power on
ipmitool <opts> chassis power cycle
ipmitool <opts> chassis power soft (Performs safe OS shutdown)
```

Changing System Boot Order

```
ipmitool <opts> chassis bootdev pxe
ipmitool <opts> chassis bootdev harddisk
ipmitool <opts> chassis bootdev cdrom
```

SEL Commands

The following command displays the date/time of last event, last log clear time, and number of entries in the system event log (SEL):

```
ipmitool <opts> sel info
```

To display the SEL, enter:

```
ipmitool <opts> sel list
```

To clear the SEL, enter:

```
ipmitool <opts> sel clear
```

