
OCTANE™ Workstation Internal DDSII DAT Drive Installation Information

This flier provides information about installing an internal DDSII DAT drive in the OCTANE workstation.

Follow these instructions to install the drive in the correct drive bay:

1. Follow the directions in the *OCTANE Workstation Owner's Guide* to power off the workstation, remove the lock bar, remove the bezel, and remove the blank panel in front of the top drive bay.
 - Place the internal DDSII DAT drive in the top drive bay only.
 - Do not install more than one DAT drive internally in the OCTANE workstation.
2. Install the drive following the directions in the owner's guide.

©1997, Silicon Graphics, Inc. All rights reserved.

Silicon Graphics and the Silicon Graphics logo are registered trademarks and OCTANE is a trademark of Silicon Graphics, Inc.

Document Number 007-3591-001

